



Złącze proste.  
Coupler - straight



Z zaworem  
With valve




Bez zaworu  
Without valve



| NR KAT.    | NR KAT.   | NW | d1 | d2    | d3  | d4 | L  | l1 |
|------------|-----------|----|----|-------|-----|----|----|----|
| CSK 060-06 | SK 060-06 | 6  | 6  | 1/4"  | 4,5 | 17 | 9  | 46 |
| CSK 060-08 | SK 060-08 |    | 8  | 5/16" | 6   | 17 | 9  | 46 |
| CSK 060-09 | SK 060-09 |    | 9  | 5/14" | 6   | 17 | 9  | 46 |
| CSK 060-10 | SK 060-10 |    | 10 | 3/8"  | 6   | 17 | 9  | 46 |
| CSK 060-13 | SK 060-13 |    | 13 | 1/2"  | 6   | 17 | 9  | 52 |
| CSK 090-10 | SK 090-10 | 9  | 10 | 3/8"  | 8   | 23 | 13 | 60 |
| CSK 090-13 | SK 090-13 |    | 13 | 1/2"  | 9   | 23 | 13 | 60 |
| CSK 190-19 | SK 190-19 | 13 | 19 | 3/4"  | 13  | 31 | 19 | 90 |


Złącze kątowe - 45°  
Coupler - angle 45°



Z zaworem  
With valve



Bez zaworu  
Without valve



| NR KAT.        | NR KAT.       | NW | d1 | d2    | d3  | d4 | L  | l1 |
|----------------|---------------|----|----|-------|-----|----|----|----|
| CSK 060-06-45° | SK 060-06-45° | 6  | 6  | 1/4"  | 4,5 | 17 | 9  | 41 |
| CSK 060-08-45° | SK 060-08-45° |    | 8  | 5/16" | 6   | 17 | 9  | 41 |
| CSK 060-09-45° | SK 060-09-45° |    | 9  | 5/14" | 6   | 17 | 9  | 41 |
| CSK 060-10-45° | SK 060-10-45° |    | 10 | 3/8"  | 6   | 17 | 9  | 41 |
| CSK 090-10-45° | SK 090-10-45° | 9  | 10 | 3/8"  | 8   | 23 | 13 | 51 |
| CSK 090-13-45° | SK 090-13-45° |    | 13 | 1/2"  | 9   | 23 | 13 | 51 |
| CSK 190-19-45° | SK 190-19-45° | 13 | 19 | 3/4"  | 13  | 31 | 19 | 78 |